SUB RIDER

Analog Octaver

OPERATION

1 - Connect the input jack to your instrument

2 - Connect the output jack to your pedal chain or directly to amplifier

CONTROLS:

2 Independent controls + sub octave frequency switch

CLEAN: Clean Level (-∞/ +6Db)

SUB OCT: Sub Octave Level(-∞/ +6Db)

SWITCH: Sub Octave frequency switch

Rear Panel Connections:

INPUT: Jack(Mono)

OUTPUT: Jack(Mono)

DC Adaptor (center negative)

Specifications:

Power Supply: 9v DC

Current Flow: 25mA

Switch: Buffer bypass

Enclosure: Stainless steel 304

Weight: 400gr

Wood Sides: Okoumè black

Size: 110x110x42mm

- 2 independent channels mixable.
- The Sub switch allows you to choose the frequency response of the octave and make the pedal more versatile in the mix.
- The Clean channel is a preamp stage and can be used standalone.

IMPORTANT: Use only power supplies for musical instruments (e.g. One Spot or superior).
FKT Audio decline any responsibility for the use of unstabilized or unsuitable power supplies.

FKT AUDIO®

Warranty

FKT Audio warranties the product to be free from defects in material and workmanship for a period of 3 years from the original date of purchase.
if the product fails within the warranty period, FKT Audio will repair or, at our discretion, replace the product at no cost to the original purchaser.

Exclusions

This warranty covers defects in manufacturing discovered while using this product as recommended by FKT Audio.
This warranty does not cover loss or theft, not does the coverage extend to damage caused by misuse,abuse, unauthorized modification, improper storage, lightning, or natural disasters.

Limits of Liability

In the case of malfunction, the product will be repaired or replaced, as described above. FKT Audio will not be liable to any party for damages arising from the failure of this product.
The following damages are not included: damage to other equipment and damages incidental to or arising from the inability to use this product.